

Powder SilkeMat® Rigidizer

INSTRUCTIONS

- **Mix 1 part dry mix to 4 parts distilled water clean in a clean container.**
- **USE A DUST MASK WHEN MIXING.**
- **Mix well and let stand 12-24 hours**
- **Stir well and mix thoroughly with an electric hand blender.**
- **Use a strainer to remove any unmixed particles. It is now reconstituted and ready to use.**
- **Keep container sealed and stir again before using, as the ingredients settle.**